

12V Voltage Regulator

- Connect the **Black** wire from the voltage regulator to a good chassis ground.
- Connect the **Green** wire from the voltage regulator to the to a switched +12VDC power source.
- Connect the **Purple** wire from the voltage regulator to the power of the speedometer as well as the power to the pulse generator or signal interface.

Caution: Only connect the speedometer and signal generator [SN16] or signal interface [SN74] to the voltage regulator. The regulator is only able to supply 500mA of power. Connecting other devices to the regulated power might overload the regulator and will void the warranty.

