

Rocket Tachometer Installation

Rocket Tachometer Wiring

- 1) Always disconnect the ground lead from the vehicle battery before wiring any gauge.
- 2) Connect a good chassis ground to terminal “1” on the back of the gauge.
- 3) Connect a switched +12VDC power source to terminal “2” on the back of the gauge.
- 4) Connect a tachometer signal to terminal “7” on the back of the gauge.
 - a. **Standard Points:** Negative (-) side of coil.
 - b. **HEI (High Energy Ignition System):** “TACH” terminal on coil side of distributor cap.
 - c. **MSD (Multiple Spark Discharge System):** Use tachometer from MSD box.
 - d. **Multiple Coil Ignition Systems:** A tachometer signal driver such as MSD #8913, which produces a 12V square wave signal, is recommended. Please check with ignition manufacturer for your specific application.
 - e. **ECM:** Computer signal requires additional SN76 signal adapter.
 - f. An additional signal converter is required for signals other than 8-cylinder.
- 5) Connect dash light power to terminal “8” on the back of the gauge.

